



SMD Micro Embedded Infrared Receiver Module

Module No.: PIC-9002ATE


Relative Reception Distance vs Transmitter Carrier Frequency




Sensitivity Diagram



In case of noisy power supply, please serially insert 100 Ω resistor and about 47 μ F electrolytic capacitor in Vcc line and ground as follows:-



Block Diagram



Standard Inspection

Among electrical characteristics, total quantity will be inspected as below:-

- ⊙ Distance between emitter and detector
- ⊙ Current consumption
- ⊙ H level output voltage
- ⊙ L level output voltage

SMD Micro Embedded Infrared Receiver Module

Module No.: PIC-9002ATE

Testing Method

Distance between emitter and detector specifies maximum distance that output waveform satisfies the standard (FIG-3) under the conditions below against the standard transmitter.

- a. Measuring place
Indoor without extreme reflection of light.
- b. Ambient light source
Detecting surface illumination is 200 ± 5 Lux under ordinary white fluorescence lamp of no high frequency lightning.
- c. Standard transmitter
Transmitter wave indicated in FIG-2 of standard transmitter is arranged to satisfy $V_o \geq 50$ mVp-p under the measuring circuit specified in FIG-3




FIG-1





FIG-3 Power Output Measurement Circuit




FIG-2

Embedded Design

This design (Fig-4) is to install a metal case on the carrier lead frame to cover the semiconductor components, in order to shield it electromagnetically within the epoxy resin encapsulation.




FIG-4 Embedded Design

Precautions for Use

- a. Store and use where there is no force causing transformation or change in quality.
- b. Store and use where there is no corrosive gas or sea (salt) breeze.
- c. Store and use where there is no extreme humidity.
- d. Solder the lead pin within the condition of ratings. After soldering, do not add exterior force.
- e. Do not wash this device. Wipe the stains of diode side with a soft cloth. You can use the solvent, ethyl alcohol, or methyl alcohol only.
- f. To prevent static electricity damage to the pre-amp, make sure that the human body, the soldering iron are connected to ground before using.